

ECE/CS 552: Performance and Cost

© Prof. Mikko Lipasti

Lecture notes based in part on slides created by Mark Hill, David Wood, Guri Sohi, John Shen and Jim Smith

Performance and Cost

 Which of the following airplanes has the best performance?

Airplane	Passengers	Range (mi)	Speed (mph)	
Boeing 737-100	101	630	598	
Boeing 747	470	4150	610	
BAC/Sud Concorde	132	4000	1350	
Douglas DC-8-50	146	8720	544	

- How much faster is the Concorde vs. the 747
- How much bigger is the 747 vs. DC-8?

Performance and Cost

- Which computer is fastest?
- Not so simple
 - Scientific simulation FP performance
 - Program development Integer performance
 - Database workload Memory, I/O

Performance of Computers

- Want to buy the fastest computer for what you want to do?
 - Workload is all-important
 - Correct measurement and analysis
- Want to design the fastest computer for what the customer wants to pay?
 - Cost is an important criterion

Forecast

- Time and performance
- Iron Law
- MIPS and MFLOPS
- Which programs and how to average
- Amdahl's law

Defining Performance

- What is important to whom?
- Computer system user
 - Minimize elapsed time for program:

$$t_{resp} = t_{end} - t_{start}$$

- Called response time
- Computer center manager
 - Maximize completion rate = #jobs/second
 - Called throughput

Response Time vs. Throughput

- Is throughput = 1/avg. response time?
 - Only if NO overlap
 - Otherwise, throughput > 1/avg. response time
 - E.g. a lunch buffet assume 5 entrees
 - Each person takes 2 minutes/entrée
 - Throughput is 1 person every 2 minutes
 - BUT time to fill up tray is 10 minutes
 - Why and what would the throughput be otherwise?
 - 5 people simultaneously filling tray (overlap)
 - Without overlap, throughput = 1/10

What is Performance for us?

- For computer architects
 - CPU time = time spent running a program
- Intuitively, bigger should be faster, so:
 - Performance = 1/X time, where X is response, CPU execution, etc.
- Elapsed time = CPU time + I/O wait
- We will concentrate on CPU time

Improve Performance

- Improve (a) response time or (b) throughput?
 - Faster CPU
 - Helps both (a) and (b)
 - Add more CPUs
 - Helps (b) and perhaps (a) due to less queueing

Performance Comparison

 Machine A is n times faster than machine B iff perf(A)/perf(B) = time(B)/time(A) = n

- Machine A is x% faster than machine B iff perf(A)/perf(B) = time(B)/time(A) = 1 + x/100
- E.g. time(A) = 10s, time(B) = 15s
 - 15/10 = 1.5 => A is 1.5 times faster than B
 - 15/10 = 1.5 => A is 50% faster than B

Breaking Down Performance

- A program is broken into instructions
 - H/W is aware of instructions, not programs

- At lower level, H/W breaks instructions into cycles
 - Lower level state machines change state every cycle

- For example:
 - 1GHz Snapdragon runs 1000M cycles/sec, 1 cycle = 1ns
 - 2.5GHz Core i7 runs 2.5G cycles/sec, 1 cycle = 0.25ns

Iron Law

Architecture --> Implementation --> Realization

Compiler Designer Processor Designer Chip Designer

Iron Law

- Instructions/Program
 - Instructions executed, not static code size
 - Determined by algorithm, compiler, ISA
- Cycles/Instruction
 - Determined by ISA and CPU organization
 - Overlap among instructions reduces this term
- Time/cycle
 - Determined by technology, organization, clever circuit design

Our Goal

- Minimize time which is the product, NOT isolated terms
- Common error to miss terms while devising optimizations
 - E.g. ISA change to decrease instruction count
 - BUT leads to CPU organization which makes clock slower
- Bottom line: terms are inter-related

Other Metrics

- MIPS and MFLOPS
- MIPS = instruction count/(execution time x 10^6) = clock rate/(CPI x 10^6)
- But MIPS has serious shortcomings

Problems with MIPS

- E.g. without FP hardware, an FP op may take 50 single-cycle instructions
- With FP hardware, only one 2-cycle instruction
 - Thus, adding FP hardware:

$$50/50 = > 2/1$$

$$50 = > 1$$

$$50 => 2$$

$$50 \text{ MIPS} \Rightarrow 2 \text{ MIPS}$$

Problems with MIPS

- Ignores program
- Usually used to quote peak performance
 - Ideal conditions => guaranteed not to exceed!
- When is MIPS ok?
 - Same compiler, same ISA
 - E.g. same binary running on AMD Jaguar, Intel
 Core i7
 - Why? Instr/program is constant and can be factored out

Other Metrics

- MFLOPS = FP ops in program/(execution time x 10⁶)
- Assuming FP ops independent of compiler and ISA
 - Often safe for numeric codes: matrix size determines # of FP ops/program
 - However, not always safe:
 - Missing instructions (e.g. FP divide)
 - Optimizing compilers
- Relative MIPS and normalized MFLOPS
 - Adds to confusion

Rules

- Use ONLY Time
- Beware when reading, especially if details are omitted
- Beware of Peak
 - "Guaranteed not to exceed"

Iron Law Example

- Machine A: clock 1ns, CPI 2.0, for program x
- Machine B: clock 2ns, CPI 1.2, for program x
- Which is faster and how much?

```
Time/Program = instr/program x cycles/instr x sec/cycle 

Time(A) = N \times 2.0 \times 1 = 2N

Time(B) = N \times 1.2 \times 2 = 2.4N

Compare: Time(B)/Time(A) = 2.4N/2N = 1.2
```

So, Machine A is 20% faster than Machine B for this program

Iron Law Example

Keep clock(A) @ 1ns and clock(B) @2ns
For equal performance, if CPI(B)=1.2, what is CPI(A)?

```
Time(B)/Time(A) = 1 = (Nx2x1.2)/(Nx1xCPI(A))CPI(A) = 2.4
```

Iron Law Example


- Keep CPI(A)=2.0 and CPI(B)=1.2
- For equal performance, if clock(B)=2ns, what is clock(A)?

```
Time(B)/Time(A) = 1 = (N \times 2.0 \times clock(A))/(N \times 1.2 \times 2)

clock(A) = 1.2ns
```

Summary

- Time and performance: Machine A n times faster than Machine B
 - Iff Time(B)/Time(A) = n
- Iron Law: Performance = Time/program =



- Other Metrics: MIPS and MFLOPS
 - Beware of peak and omitted details



ECE/CS 552: Benchmarks, Means and Amdahl's Law

© Prof. Mikko Lipasti

Lecture notes based in part on slides created by Mark Hill, David Wood, Guri Sohi, John Shen and Jim Smith

Which Programs



- Execution time of what program?
- Best case you always run the same set of programs
 - Port them and time the whole workload
- In reality, use benchmarks
 - Programs chosen to measure performance
 - Predict performance of actual workload
 - Saves effort and money

Representative? Honest? Benchmarketing...





	Machine A	Machine B
Program 1	1	10
Program 2	1000	100
Total	1001	110

 One answer: for total execution time, how much faster is B?

$$1001 / 110 = 9.1x$$

How to Average



- Another: arithmetic mean (same result)
- Arithmetic mean of times:

•
$$AM(A) = 1001/2 = 500.5$$

•
$$AM(B) = 110/2 = 55$$

- Speedup: 500.5/55 = 9.1x
- Valid only if programs run equally often, so use weighted arithmetic mean:

$$\left\{ \sum_{i=1}^{n} \left(weight(i) \times time(i) \right) \right\} \times \frac{1}{n}$$

$$\left\{\sum_{i=1}^{n} time(i)\right\} \times \frac{1}{n}$$


Other Averages



- E.g., 30 mph for first 10 miles, then 90 mph for next 10 miles, what is average speed?
- Average speed = (30+90)/2 WRONG
- Average speed = total distance / total time
 - = (20 / (10/30 + 10/90))
 - =45 mph

Harmonic Mean

Harmonic mean of rates =



- Use HM if forced to start and end with rates (e.g. reporting MIPS or MFLOPS)
- Why?
 - Rate has time in denominator
 - Mean should be proportional to inverse of sums of time (not sum of inverses)
 - See: J.E. Smith, "Characterizing computer performance with a single number," CACM Volume 31, Issue 10 (October 1988), pp. 1202-1206.





	Machine A	Machine B
Program 1	1	10
Program 2	1000	100
Total	1001	110

If we take ratios with respect to machine A

	Machine A	Machine B
Program 1	1	10
Program 2	1	0.1
Average	1	5.05

Dealing with Ratios



- Avg. wrt. machine A: A is 1, 5.05
- If we take ratios with respect to machine B


	Machine A	Machine B
Program 1	0.1	1
Program 2	10	1
Average	5.05	1

- Can't both be true!!!
- Don't use arithmetic mean on ratios!

Geometric Mean



- Use geometric mean for ratios
- Geometric mean of ratios =



- Independent of reference machine
- In the example, GM for machine a is 1, for machine B is also 1
 - Normalized with respect to either machine

But...



- GM of ratios is not proportional to total time
- AM in example says machine B is 9.1 times faster
- GM says they are equal
- If we took total execution time, A and B are equal only if
 - Program 1 is run 100 times more often than program 2
- Generally, GM will mispredict for three or more machines

Summary



- Use AM for times
- Use HM if forced to use rates
- Use GM if forced to use ratios

 Best of all, use unnormalized numbers to compute time

Benchmarks: SPEC2000



- System Performance Evaluation Cooperative
 - Formed in 80s to combat benchmarketing
 - SPEC89, SPEC92, SPEC95, SPEC2000, SPEC2006
- 12 integer and 14 floating-point programs
 - Sun Ultra-5 300MHz reference machine has score of 100
 - Report GM of ratios to reference machine

Benchmarks: SPEC CINT2000



Benchmark	Description
164.gzip	Compression
175.vpr	FPGA place and route
176.gcc	C compiler
181.mcf	Combinatorial optimization
186.crafty	Chess
197.parser	Word processing, grammatical analysis
252.eon	Visualization (ray tracing)
253.perlbmk	PERL script execution
254.gap	Group theory interpreter
255.vortex	Object-oriented database
256.bzip2	Compression
300.twolf	Place and route simulator





Benchmark	Description
168.wupwise	Physics/Quantum Chromodynamics
171.swim	Shallow water modeling
172.mgrid	Multi-grid solver: 3D potential field
173.applu	Parabolic/elliptic PDE
177.mesa	3-D graphics library
178.galgel	Computational Fluid Dynamics
179.art	Image Recognition/Neural Networks
183.equake	Seismic Wave Propagation Simulation
187.facerec	Image processing: face recognition
188.ammp	Computational chemistry
189.lucas	Number theory/primality testing
191.fma3d	Finite-element Crash Simulation
200.sixtrack	High energy nuclear physics accelerator design
301.apsi	Meteorology: Pollutant distribution

Benchmark Pitfalls



- Benchmark not representative
 - Your workload is I/O bound, SPEC is useless
- Benchmark is too old
 - Benchmarks age poorly; benchmarketing pressure causes vendors to optimize compiler, hardware, software to match benchmarks
 - Need to be periodically refreshed

Amdahl's Law



- Motivation for optimizing common case
- Speedup = old time / new time = new rate / old rate
- Let an optimization speed fraction f of time by a

```
Math: If f is small, s will speed have limited speed impact.

Spee
```

$$Speedup = \frac{[(1-f)+f] \times oldtime}{[(1-f) \times oldtime] + \frac{f}{s} \times oldtime}$$
$$= \frac{1}{1-f+\frac{f}{s}}$$

Amdahl's Law Example



- Your boss asks you to improve performance by:
 - Improve the ALU used 95% of time by 10%
 - Improve memory pipeline used 5% of time by 10x

f	S	Speedup
95%	1.10	1.094
5%	10	1.047
5%	∞	1.052


$$Speedup = \frac{1}{1 - f + \frac{f}{s}}$$

Amdahl's Law: Limit



Make common case fast:

$$\lim_{s \to \infty} \frac{1}{1 - f + \frac{f}{s}} = \frac{1}{1 - f}$$



Amdahl's Law: Limit



- Consider uncommon case!
- If (1-f) is nontrivial
 - Speedup is limited!

$$\lim_{s \to \infty} \frac{1}{1 - f + \frac{f}{s}} = \frac{1}{1 - f}$$

- Particularly true for exploiting parallelism in the large, where large s is not cheap
 - GPU with e.g. 1024 processors (shader cores)
 - Parallel portion speeds up by s (1024x)
 - Serial portion of code (1-f) limits speedup

E.g. 10% serial portion: 1/0.1 = 10x speedup with 1000 cores





- Benchmarks: SPEC2000
- Summarize performance:
 - AM for time
 - HM for rate
 - GM for ratio
- Amdahl's Law:

$$Speedup = \frac{1}{1 - f + \frac{f}{s}}$$