SPARC Overview

- SPARC is an acronym for Scalable Processor ARChitecture
- SPARCs are load/store RISC processors
 Load/store means only loads and stores access memory directly.
 RISC (Reduced Instruction Set Computer) means the architecture is simplified with a limited number of instruction formats and addressing modes.

Instruction format:

add %r1,%r2,%r3

Registers are prefixed with a % Result is stored into last operand.

ld [adr],%r1

Memory addresses (used only in loads and stores) are enclosed in brackets

• Distinctive features include *Register Windows* and *Delayed Branches*

CS 701 Fall 2001

26

CS 701 Fall 2001[®]

__

Register Windows

The SPARC provides 32 general-purpose integer registers, denoted as %r0 through %r31.

These 32 registers are subdivided into 4 groups:

Globals: %g0 to %g7
In registers: %i0 to %i7
Locals: %10 to %17
Out registers: %o0 to %o7

There are also 32 floating-point registers, **%f0** to **%f31**.

A SPARC processor has an implementation-dependent number of *register windows*, each consisting of 16 distinct registers. The "in", "local" and "out" registers that are accessed in a procedure depend on the current register window. The "global"

registers are independent of the register windows (as are the floating-point registers).

A register window may be pushed or popped using SPARC save and restore instructions.

After a register window push, the "out" registers become "in" registers and a fresh set of "local" and "out" registers is created:

Before save:

In	Local	Out		_
In	Local	In	Local	Out
(old)	(old)		(new)	(new)

After save

Why the overlap between "in" and "out" registers? It's a convenient way to pass parameters—the caller puts parameter values in his "out" registers. After a call (and a save) these values are automatically available as "in" registers in the newly created register window.

SPARC procedure calls normally advance the register window. The "in" and "local" registers become hidden, and the "out" registers become the "in" registers of the called procedure, and new "local" and "out" registers become available.

A register window is advanced using the **save** instruction, and rolled back using the **restore** instruction. These instructions are separate from the procedure **call** and **return** instructions, and can sometimes be optimized away.

For example, a *leaf procedure*—one that contains no calls—can be compiled without use of **save** and **restore** if it doesn't need too many registers. The leaf procedure must then make do with the caller's registers, modifying only those the caller treats as volatile.

SS 701 Fall 2001[®] 30 CS 701 Fall 2001[®] 3

Register Conventions

Global Registers

%g0 is unique: It *always* contains 0 and can *never* be changed.

%g1 to %g7 have global scope (they are unaffected by save and restore instructions)

%g1 to **%g4** are volatile across calls; they may be used between calls.

%g5 to %g7 are reserved for special use by the SPARC ABI (application binary interface)

Local Registers

%10 to %17

May be freely used; they are unaffected by deeper calls.

In Registers

These are also the caller's out registers; they are unaffected by deeper calls.

%i0

Contains incoming parameter 1.

Also used to return function value to caller.

%i1 to %i5

Contain incoming parameters 2 to 6 (if needed); freely usable otherwise.

%i6 (also denoted as %fp)

Contains frame pointer (stack pointer of caller); it must be preserved.

%i7

Contains return address -8 (offset due to delay slot); it must be preserved.

Out Registers

Become the in registers for procedures called from the current procedure.

%00

Contains outgoing parameter 1.

It also contains the value returned by the called procedure.

It is volatile across calls; otherwise it is freely usable.

%o1 to %o5

Contain outgoing parameters 2 to 6 as needed.

These are volatile across calls; otherwise they are freely usable.

%o6 (also denoted as %sp)

Holds the stack pointer (and becomes frame pointer of called routines)

It is reserved; it must *always* be valid (since TRAPs may modify the stack at any time).

%o7

Is volatile across calls.

It is loaded with address of caller on a procedure call.

CS 701 Fall 2001[©]

CS 701 Fall 2001[®]

...

Special SPARC Instructions

save %r1,%r2,%r3

save %r1,const,%r3

This instruction pushes a register window and does an add instruction (%r3 = %r1+%r2). Moreover, the operands (%r1 and %r2) are from the old register window, while the result (%r3) is in the new window.

Why such an odd definition?

It's ideal to allocate a new register window and push a new frame.

In particular,

frame pointer)

save %sp,-frameSize,%sp
pushes a new register window. It also
adds -frameSize (the stack grows
downward) to the old stack pointer,
initializing the new stack pointer. (The
old stack pointer becomes the current

restore %r1,%r2,%r3

restore %r1,const,%r3

This instruction pops a register window and does an add instruction (%r3 = %r1+%r2). Moreover, the operands (%r1 and %r2) are from the current register window, while the result (%r3) is in the old window.

Why such an odd definition?

It's ideal to release a register window and place a result in the return register (%00).

In particular,

restore %r1,0,%o0

pops a register window. It also moves the contents of %r1 to %o0 (in the caller's register window).

call label

This instruction branches to label and puts the address of the call into register %o7 (which will become %i7 after a save is done).

ret

This instruction returns from a subprogram by branching to %i7+8. Why 8 bytes after the address of the call? SPARC processors have delayed branch instructions, so the instruction immediately after a branch (or a call) is executed before the branch occurs! Thus two instructions after the call is the normal return point.

const,%r1 mov

> You can load a small constant (13 bits or less) into a register using a mov. (mov is actually implemented as an or of const with %q0).

But how do you load a 32 bit constant? One instruction (32 bits long) isn't enough. Instead you use:

sethi %hi(const),%r1 or %r1,%lo(const),%r1

That is, you extract the high order 22 bits of const (using %hi, an assembler operation). sethi fills in these 22 bits into %r1, clearing the lowest 10 bits. Then %10 extracts the 10 low order bits of const, which are or-ed into %r1.

CS 701 Fall 2001[®]

Loading a 64 bit constant (in SPARC V9, which is a 64 bit processor) is far nastier:

sethi %uhi(const),%r_{tmp} %r_{tmp},%ulo(const),%r_{tmp} orsllx%r_{tmp},32,%r_{tmp} sethi %hi(const),%r %r,%lo(const),%r or

%r_{tmp},%r,%r

or

Delayed Branches

In the SPARC, transfers of control (branches, calls and returns) are delayed. This means the instruction after the branch (or call or return) is executed before the transfer of control.

For example, in SPARC code you often see

ret

restore

The register window restore occurs first, then a return to the caller occurs.

Another example is

call subr mov 3,%00

The load of **subr**'s parameter is placed after the call to **subr**. But the **mov** is done before **subr** is actually called.

Why are Delayed Branches Part of the SPARC Architecture?

Because of pipelining, several instructions are partially completed before a branch instruction can take effect. Rather than lose the computations already done, one (or more!) partially completed instructions can be allowed to complete before a branch takes effect.

How does a Compiler Exploit Delayed Branches?

A peephole optimizer or code scheduler looks for an instruction logically before the branch that can be placed in the branch's *delay slot*. The instruction should not affect a conditional branch's branch decision.

```
mov 3,%00 call subr
call subr mov 3,%00
nop
(before) (after)
```

CS 701 Fall 2001[©]

CS 701 Fall 2001[©] 43

Another possibility is to "hoist" the target instruction of a branch into the branch's delay slot.

```
call subr call subr+4
nop mov 100,%11
...
subr: subr:
mov 100,%11 mov 100,%11
(before) (after)
```

Hoisting branch targets doesn't work for conditional branches—we don't want to move an instruction that is executed *sometimes* (when the branch is taken) to a position where it is *always* executed (the delay slot).

Annulled Branches

An annulled branch (denoted by a ",a" suffix) executes the instruction in the delay slot if the branch is taken, but ignores the instruction in the delay slot if the branch isn't taken.

With an annulled branch, a target of a conditional branch can be hoisted into the branch's delay slot.


```
bz else bz,a else+4
nop mov 100,%11
! then code ! then code
...
else: else:
mov 100,%11 mov 100,%11
(before) (after)
```

CS 701 Fall 2001[®] 44 CS 701 Fall 2001[®] 45

42

SPARC Frame Layout (on Run-Time Stack)

The Stack Grows Downward



Minimum frame Size (in gcc) is 112 bytes! (16+1+6+4 words, double aligned)

```
int incr(int i){
```

```
return i+1; }
Unoptimized:
 incr:
              %sp, -112, %sp
      save
              %i0, [%fp+68]
      st
     ld
              [%fp+68], %o1
              %01, 1, %00
      add
     mov
              %o0, %i0
              .LL2
     b
           nop
  .LL2:
     ret
     restore
```

CS 701 Fall 2001[©]

```
CS 701 Fall 2001<sup>®</sup> 46
```

```
main(){
 int
     int a;
     return incr(a);}
Unoptimized:
 main:
    save
             %sp, -120, %sp
    ld
             [%fp-20], %o0
             incr, 0
    call
    nop
    mov
             %o0, %i0
             .LL3
    b
    nop
 .LL3:
    restore
```

```
int incr(int i){
     return i+1; }
Optimized:
 incr:
     retl
     add
           %00, 1, %00
 int
        main(){
     int a;
     return incr(a);}
Optimized:
 main:
            %sp, -112, %sp
    save
 ! Where is a ????
    call
            incr, 0
    nop
    restore %g0, %o0, %o0
```

With More Extensive Optimization (including inlining) we get:

CS 701 Fall 2001[®]