


Wireless Networking


CS 407

The Networking Stack




What do they do?


The Seven Layers of OSI



What matters?



Examples



TCP

- Transmission Control Protocol
 - Connection-oriented
 - Reliable
 - Congestion Control
 - Flow Control
 - “End-to-end” semantics
-
- Source and Destination IP and port numbers

UDP

- User Datagram Protocol
 - Connectionless
 - Unreliable
-
- Source and Destination IP and port numbers

Wireless networking

- No wires!
- Shared media
- Interference and noise
- Bandwidth and range limits
- Variable performance
- Mobility
- Implications for higher network layers

Understand your assumptions

- Disconnected operations
- Delay tolerant
- Always on

Cellular vs WiFi



Cost: Expensive licensed spectrum

Range: 1 to 20 km

Tx power: 1-10 W

Protocols: Highly coordinated

Throughputs: ~ 10 Kbps – 2 Mbps



Cost: Cheap and unlicensed use

Range: ~100 m



Tx power: ~0.1 W

Protocols: Uncoordinated

Throughputs: ~ 1 Mbps – 100 Mbps

Cellular network planning

- Ideal - Hexagonal patterns



- In real life – Macro and Microcells

Impact of Wireless Environment on Networks

- The wireless spectrum
- Physical impairments
- Contention for the shared medium
- Effects of mobility
- Restrictions on terminal equipment
- Security

Wireless Spectrum (1)




Broadcast TV

- VHF: 54 to 88 MHz, 174 to 216 MHz
- UHF: 470 to 806 MHz



FM Radio

- 88 to 108 MHz



Digital TV

- 54 to 88 MHz, 174 to 216 MHz, 470 to 806 MHz




Wireless Spectrum (2)




3G Broadband Wireless

- 746-794 MHz, 1.7-1.85 GHz, 2.5-2.7 GHz



Wireless Spectrum (3)




Physical Impairments: Noise

- Unwanted signals added to the message signal
- May be due to signals generated by natural phenomena such as lightning or man-made sources, including transmitting and receiving equipment as well as spark plugs in passing cars, wiring in thermostats, etc.
- Sometimes modeled in the aggregate as a random signal in which power is distributed uniformly across all frequencies (white noise)
- Signal-to-noise ratio (SNR) often used as a metric in the assessment of channel quality

Physical Impairments: Interference

- Signals generated by communications devices operating at roughly the same frequencies may interfere with one another
 - Example: IEEE 802.11b and Bluetooth devices, microwave ovens, some cordless phones
 - CDMA systems (many of today's mobile wireless systems) are typically interference-constrained
- Signal to interference and noise ratio (SINR) is another metric used in assessment of channel quality

Physical impairments: Fading (1)



Physical impairments: Fading (2)


- Strength of the signal decreases with distance between transmitter and receiver: path loss
 - Usually assumed inversely proportional to distance to the power of 2.5 to 5
- Slow fading (shadowing) is caused by large obstructions between transmitter and receiver
- Fast fading is caused by scatterers in the vicinity of the transmitter

Diversity

- A diversity scheme extracts information from multiple signals transmitted over different fading paths
- Appropriate combining of these signals will reduce severity of fading and improve reliability of transmission
- In space diversity, antennas are separated by at least half a wavelength
 - Other forms of diversity also possible
 - Polarization, frequency, time diversity




Contention for the Medium



- If A and B simultaneously transmit to C over the same channel, C will not be able to correctly decode received information: a collision will occur
- Need for medium access control mechanisms to establish what to do in this case (also, to maximize aggregate utilization of available capacity)

Effects of Mobility



- Destination address not equal to destination location
- Addressing and routing must be taken care of to enable mobility
- Can be done automatically through handoff or may require explicit registration by the mobile in the visited network
- Resource management and QoS are directly affected by route changes

Form Factors


- Form factors (size, power dissipation, ergonomics, etc.) play an important part in mobility and nomadicity
 - Mobile computing: implies the possibility of seamless mobility
 - Nomadic computing: connections are torn down and re-established at new location
- Battery life imposes additional restrictions on the complexity of processing required of the mobiles units

Medium sharing approaches

- Time division multiple access (TDMA)
- Frequency division multiple access (FDMA)
- Code division multiple access (FDMA)

TDMA

- Examples
 - GSM
 - IS136
 - iDen
 - DECT
 - Satellite communications



TDMA

- Advantages


- Active only during own time slot, can do anything else in other time slots
 - Measure the channel, search for other transmitters in different frequencies, etc.
 - Facilitates inter-frequency handoffs efficiently (imagine a macrocell and a microcell operating in the same region with different frequencies)

- Disadvantages

- Need guard slots to protect between two transmitters (to avoid very tight synchronization)
- This wastes capacity of the channel


FDMA

- Frequency Division Multiple Access



- Each user is given a separate “channel”
 - Channels are independent of each other
-
- Needs to implement guard band between channels


CDMA



- Use pseudorandom sequences that are orthogonal (cancel out)

CDMA example

- Assume dot product
- 4 orthogonal codes
 - $a.b = 0$



CDMA example

- Consider a simpler model of 2 bit codes
 - Sender 0: (1, -1) and Sender 1: (1, 1)
 - Data: 1, 0, 1, 1 Data: 0, 0, 1, 1
 - Encoded sender 0: (1, -1, -1, 1, 1, -1, 1, -1)
 - Encoded sender 1: (-1, -1, -1, -1, 1, 1, 1, 1)
- Simultaneous transmit in medium:
 - (0, -2, -2, 0, 2, 0, 2, 0)

CDMA example

- Simultaneous transmit in medium:
 - $(0, -2, -2, 0, 2, 0, 2, 0)$
- Sender 0 code: $(1, -1)$
- Multiply received pattern with sender code
 - $((0, -2), (-2, 0), (2, 0), (2, 0)) \cdot (1, -1)$
 $= (2, -2, 2, 2), \text{ i.e., } 1, 0, 1, 1$

CDMA example

- Sender 0 code = a , data = x
- Sender 1 code = b , data = y
- Sent $a.x + b.y$
- Decode $a.(a.x + b.y) = (a.a) x + a.b.y = (a.a) x$

CDMA

- Advantages
 - Avoids narrow-band interference
 - Does not require strong coordination across different transmitters
 - Uses much more bandwidth than minimum requirements
 - Can allow a single handset to simultaneously talk to two different base stations (use two codes) and achieves better handoffs
- Disadvantages
 - Need to balance transmit power of different transmitters

Asynchronous CDMA

- Synchronous CDMA assumes all users synchronized and use orthogonal codes
- In asynchronous, each user picks a pseudo-random code, and there is some unwanted interference from other sources
 - Equalizing received power from different sources is an important necessity
 - Adding more users, adds to the noise level and so gracefully degrades performance


Generations in Mobile Wireless Service

- First Generation (1G)
 - Mobile voice services
- Second Generation (2G)
 - Primarily voice, some low-speed data (circuit switched)
- Generation 2½ (2.5G)
 - Higher data rates than 2G
 - A bridge (for GSM) to 3G
- Third Generation (3G)
 - Seamless integration of voice and data
 - High data rates, full support for packet switched data

Evolution of Mobile Wireless (1)

Advance Mobile Phone Service (AMPS)

- FDMA
- 824-849 MHz (UL), 869-894 MHz (DL)
- U.S. (1983), So. America, Australia, China



European Total Access Communication System (E-TACS)

- FDMA
- 872-905 MHz (UL), 917-950 MHz (DL)
- Deployed throughout Europe

Cellular generations

- 1G – AMPS
 - Advanced mobile phone systems
 - Used a FDMA style communication system
 - Separate channel for each user
 - Allowed for spatial frequency re-use
 - Limitations:
 - Analog and hence susceptible to noise, eavesdropping
 - Can overhear ESN and replay



Cellular generations


- 1G
 - Had separate uplink and downlink frequencies
 - 824 to 849 MHz (uplink)
 - 869 to 894 MHz (downlink)
 - Each channel was 30 KHz wide



Evolution of Mobile Wireless (2)

Global System for Mobile communications (GSM)

- TDMA
- Different frequency bands for cellular and PCS
- Developed in 1990, expected >1B subscriber by end of 2003




IS-95

- CDMA
- 800/1900 MHz – Cellular/PCS
- U.S., Europe, Asia

Evolution of Mobile Wireless (3)

General Packet Radio Services (GPRS)

- Introduces packet switched data services for GSM
- Transmission rate up to 170 kbps
- Some support for QoS



Enhanced Data rates for GSM Evolution (EDGE)

- Circuit-switched voice (at up to 43.5 kbps/slot)
- Packet-switched data (at up to 59.2 kbps/slot)
- Can achieve on the order of 475 kbps on the downlink, by combining multiple slots

Cellular generations

- 2G
 - GSM or Global System for Mobile Communications (voice)
 - 2.5G
 - Data extensions were called GPRS (Generalized Packet Radio Services)
 - Speeds further increased in EDGE (Enhanced Data rates for GSM Evolution)
 - Communication channels: 850/1900 MHz (Canada/US) or 900/1800 MHz
 - Uses TDMA communication


Cellular generations

- 2G
 - IS95
 - CDMA (Code Division Multiple Access)
 - CDMA allows parallel communication at the same time and frequency but using separate codes

Evolution of Mobile Wireless (4)

Universal Mobile Telecommunication Systems (UMTS)

- Wideband DS-CDMA
- Bandwidth-on-demand, up to 2 Mbps
- Supports handoff from GSM/GPRS



IS2000

- CDMA2000: Multicarrier DS-CDMA
- Bandwidth on demand (different flavors, up to a few Mbps)
- Supports handoff from/to IS-95

Fixed Wireless

- Microwave
 - Traditionally used in point-to-point communications
 - Initially, 1 GHz range, more recently in the 40 GHz region
- Local Multipoint Distribution Service (LMDS)
 - Operates around 30 GHz
 - Point-to-multipoint, with applications including Internet access and telephony
 - Virginia Tech owns spectrum in SW VA and surroundings
- Multichannel Multipoint Distribution Service (MMDS)
 - Operates around 2.5 GHz
 - Initially, for TV distribution
 - More recently, wireless residential Internet service

WLANs: IEEE 802.11 Family

- 802.11 working group
 - Specify an open-air interface between a wireless client and a base station or access point, as well as among wireless clients
- IEEE 802.11a
 - Up to 54 Mbps in the 5 GHz band
 - Uses orthogonal frequency division multiplexing (OFDM)
- IEEE 802.11b (Wi-Fi)
 - 11 Mbps (with fallback to 5.5, 2 and 1 Mbps) in the 2.4 GHz band
 - Uses DSSS
- IEEE 802.11g
 - 20+ Mbps in the 2.4 GHz band

WLANs/WPANs: Bluetooth

- Cable replacement technology
- Short-range radio links
- Small, inexpensive radio chip to be plugged into computers, phones, palmtops, printers, etc.
- Bluetooth was invented in 1994
- Bluetooth Special Interest Group (SIG) founded in 1998 by Ericsson, IBM, Intel, Nokia and Toshiba to develop an open specification
 - Now joined by > 2500 companies


IEEE 802.11

- Characteristics
- Modes of operation
- Association, authentication and privacy

IEEE 802.11 Standard

- Final draft approved in 1997
- Operates in the 2.4 GHz industrial, scientific and medical (ISM) band
- Standard defines the physical (PHY) and medium access control (MAC) layers
 - Note that the 802.11 MAC layer also performs functions that we usually associated with higher layers (e.g., fragmentation, error recovery, mobility management)
- Initially defined for operation at 1 and 2 Mbps
 - DSSS, FHSS or infrared
 - Extensions (IEEE 802.11b, IEEE 802.11a, etc.) allow for operation at higher data rates and (in the case of 802.11a) different frequency bands

Reference Model (1)




Reference Model (2)

- Physical Medium Dependent (PMD) sublayer
 - Defines a method for transmitting and receiving data through the medium, including modulation and coding
 - Dependent on whether DSSS, FHSS or IR is used
- Physical Layer Convergence Procedure (PLCP) sublayer
 - Maps MAC layer PDUs into a packet suitable for transmission by the PMD sublayer
 - Performs carrier sensing
- MAC sublayer
 - Defines access mechanism, based on CSMA
 - Performs fragmentation and encryption of data packets

IEEE 802.11b


- Standard released in 1999
- 2.4 – 2.483 GHz band
- Uses DSSS
- Data rates of up to 11 Mbps
 - Data rates are automatically adjusted for noisy conditions, so can operate at 1, 2, 5.5 or 11 Mbps
- Modes of operation
 - Infrastructure-based
 - Ad-hoc
- Most widely implemented to date

Infrastructure Mode (1)




- Basic Service Set (BSS)
- Access point serves as a local bridge
- Stations communicate through the access point, which relays frames to/from mobile stations

Infrastructure Mode (2)



- Extended Service Set (ESS)
- A set of infrastructure BSSs
- Access points communicate among themselves to forward frames between BSSs and to facilitate movement of stations between BSSs

Ad Hoc Mode




- Independent Basic Service Set (IBSS) or Peer to Peer
- Stations communicate directly with each other
- When no direct link is feasible between two station, a third station may act as a relay (multi-hop communications)


Distribution Systems

- The architectural component used to interconnect BSSs is the distribution system (DS)
- DS enable mobile device support
 - Address-to-destination mapping
 - Seamless integration of several BSSs
- In practice, an access point implements DS services

Distribution Systems and Access Points



Integration with Wired LANs



Association

- To deliver a message within the DS, must know which AP to access for a given mobile station
- Before a station is allowed to send a message through an AP, it must associate itself with that AP
 - At any given time, a station must be associated with no more than one AP
 - An AP may be associated with multiple stations
- As it moves between BSSs, a mobile station may reassociate itself with a different AP

Authentication

- 802.11 provides link-level authentication between stations
- 802.11 also supports shared key authentication
 - Requires that wired equivalent privacy (WEP) be enabled
 - Identity is demonstrated by knowledge of a shared, secret, WEP encryption key
- Typically, authentication is performed at association with an AP

Privacy

- Default state is “in the clear” – messages are *not* encrypted
- Optional privacy mechanism, WEP, is provided
 - Goal is to achieve a level of security at least as good as in a wired LAN
- Note that encryption provided by WEP is relatively easy to break

Bluetooth

- Characteristics
- Comparison with IEEE 802.11

Introduction

- Motivation: cable replacement in peripherals and embedded devices
- Named after Harald Blaatand “Bluetooth” II, king of Denmark 940-981 A.D.
- Estimated > 670 M Bluetooth-enabled devices by 2005



Requirements



Bluetooth phone
and headset



Bluetooth
printer module

- Universal framework to integrate a diverse set of devices in a seamless, user-friendly, efficient manner
- Devices must be able to establish ad hoc connections
- Support for data and voice
- Similar security as cables
- Simple, small, power-efficient implementation
- Inexpensive!

Characteristics

- Operates in the ISM band (like 802.11b)
- Frequency hopping spread spectrum
- Up to 720 kbps data transfer with a range of 10 m
 - Transmission rate decreases if interference from other devices is present
- Master/slave architecture
 - A collection of master + slaves is called a piconet
 - Up to 7 slave devices may communicate with a master
 - Piconets can be linked together to form a scatternet

Comparison with 802.11

Characteristic	Bluetooth	IEEE 802.11b	IEEE 802.11a
Spectrum	2.4 GHz	2.4 GHz	5 GHz
Max Data Rate	725 kbps	11 Mbps	54 Mbps
Connections	Point-to-Multipoint	Point-to-Point	Point-to-Point
Frequency Selection	FHSS	DSSS	OFDM
Circuit cost (est. 2001)	\$ 11.00	\$ 46.00	N/A